

## TECHNICAL SPECIFICATION

USB	
Signal Type	USB 2.0
Input Interface (TX)	(1) USB Type B (Female)
Output Interface (RX)	(4) USB Type A (Female)
OTHER	
Power	External 100-240 VAC/5VDC3A
Dimensions	4.3" W x 1.1" H x 2.5" D
Weight	1.5 lb
Operating Temp.	0-55 °C (32-131 °F)
Storage Temp.	-20-85 °C (-4-185 °F)
Humidity	Up to 95% (non-condensing)

## WHAT'S IN THE BOX

PART NO.	Q-TY	DESCRIPTION
USB2FX-TX	1	USB 2.0 over Fiber Transmitter
USB2FX-RX	1	USB 2.0 over Fiber Receiver
PS5VD3A	2	5V 3A Power Supply
Quick Start Guide	1	

## NOTICE

The information contained in this document is subject to change without notice. SmartAVI makes no warranty of any kind with regard to this material, including but not limited to, implied warranties of merchantability and fitness for particular purpose.

SmartAVI will not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

No part of this document may be photocopied, reproduced, or translated into another language without prior written consent from SmartAVI Technologies, Inc.



(888)-994-7427, (702)-800-0005  
2455 W Cheyenne Ave, Suite 112  
North Las Vegas, NV 89032

[SmartAVI.com](http://SmartAVI.com)

**Smart-AVI**  
SMART AUDIO VIDEO INNOVATION

# USB2FX

## USB 2.0 Extender over Fiber



**EXTENDS USB 2.0  
UP TO 10 KM  
OVER FIBER CABLE  
IN SINGLE MODE**

**Quick Start Guide**

## OVERVIEW


SmartAVI's extends standard USB (Universal Serial Bus) 2.0 signals up to 10 km (6.2 miles) in Single mode and 500 ft in Multimode using a single fiber cable. The USB2FX supports all USB 2.0 high-speed devices, from keyboards to digital cameras, and will operate on Windows®, Mac® and Linux® operating systems. An integrated four-port hub allows for multiple devices to be connected to the USB2FX at once. Additional USB hubs can be added, increasing the number of devices that can be plugged into the USB2FX.

## FEATURES

- Extend USB2.0 up to 10 km in Single mode and 500 ft in Multimode
- Supports All USB 2.0 and 1.1 Devices Transparently (Flash Drives, Printers, Cameras, Scanners, etc.)
- Supports USB 1.1 Keyboard and Mouse
- Works on Windows, Mac and Linux Operating Systems
- Integrated Four-Port Hub
- How-swappable SFP module
- Power Adapter for Remote Unit
- Plug-and-Play




USB2FX-TX Front panel



USB2FX-TX Back panel



USB2FX-RX Front panel



USB2FX-RX Back panel

## HARDWARE INSTALLATION

### USB2FX-TX Transmitter

1. Power off all devices.
2. Connect the KM source device (computer) to the USB2FX-TX with a USB cable using the USB-B input port.
3. Insert an SFP transceiver into the SFP uplink port on the USB2FX-TX transmitter.
4. Install a fiber-optic cable into the SFP transceiver attached to the USB2FX-TX transmitter.
5. Connect a power supply to the USB2FX-TX.

### USB2FX-RX Receiver

1. Insert an SFP transceiver into the SFP uplink port on the USB2FX-RX receiver.
2. Install the fiber-optic cable into the SFP transceiver attached to the USB2FX-RX receiver.
3. Connect the USB2FX-RX to the desired peripherals using the USB-A output ports.
4. Connect a power supply to the USB2FX-RX.
5. Power on all devices.

